

Zones on the CM6700

Here's how zones work on the CM6700. To enter the zone programming menu press 81-88 F4. 81 F4 programs zone 1, 82 F4 zone 2 ... 88 F4 zone 8. Like presets, if you enter zones programming accidentally, pressing the PGM key causes the menu to be exited with no change. Edit the label just as in setting a preset by using the joystick to move from character to character, and the F1, F2 keys to change characters forward or backward. After editing the label, move to the SET line. The S in set will be blinking. Press the ACK key or perform the right function (joystick right KBD300, right arrow KBD200). The dome displays the label. Pan the dome clockwise to the zone end and press 81-88 F5 depending on the zone you are programming. 81 F5 ends zone 1, 82 F5 ends zone 2 ... 88 F5 ends zone 8. To turn zones on, press 88 preset. Pressing 89 preset turns zones off.

Zones Note:

Zones are prioritized with the highest zone number taking highest priority. When two zones overlap, the highest priority zone label appears. If for example zone 1 overlaps zone 8, zone 8's label is displayed in the overlapping area.

Here is the zone Menu that appears after pressing 81 – 88 F4:

ZONE X START After zone
start set, pan to zone
end and press 8X F5.
A
SET

Like presets the first character of the label, A, is blinking and ready for editing upon entering the menu. The X is the number of the zone being edited 1-8.